

2001-2010 CHEVY EFI DMAX FUSE

Installation Guide

Read the complete guide before beginning. Keep removed hardware organized, follow all safety precautions, and verify all connections before operating the vehicle.



Year	Engine	Pull Fuse	Pull Fuse	Pull Fuse	Pull Fuse	LOCATION
2010	LMM	INFO TMNT	RDO	IPC		CAB/HOOD
2009	LMM	INFO TMNT	RDO	IPC		CAB/HOOD
2008	LMM	INFO TMNT	RDO	IPC		CAB/HOOD
2007.5	LMM	INFO (TMNT)	RDO	IPC		CAB/HOOD
2007	LBZ	**INFO	**RADIO			HOOD
2006.5	LBZ	**INFO	**RADIO			HOOD
2006	LLY2	**INFO	**RADIO			HOOD
2005	LLY	TBC BATT	TBC IGNITION	INFO	RADIO	HOOD
2004.5	LLY	TBC BATT	TBC IGNITION	INFO	RADIO	HOOD
2004	LB7	TBC BATT	TBC IGNITION	INFO	RADIO	HOOD
2003	LB7	TBC BATT	TBC IGNITION	INFO	RADIO	HOOD
2002	LB7	SEO-1	SEO-2			CAB
2001	LB7	SEO-1	SEO-2			CAB

Installation reference - page 2

2001-2002 Duramax: 1. pull fuses SEO IGN, RDO1, RAP2. 2. Once the download is complete, reinstall all fuses.

2003-2005 Duramax: 1. pull fuses: TBC BATT, TBC IGN1, RADIO, INFO. 2. Once the download is complete, reinstall all fuses.

LB7 and LLY Tips & Tricks

LB7 and LLY controllers use a communications platform that is not very robust and was replaced in 2006. In many cases, these controllers fail with factory tools and will be unrecoverable.

Tips for successful reading/flash of LB7 and LLY controllers include: 1. Use a bench harness for reading/flash

(Recommended). 2. Remove/isolate all aftermarket devices including

mobile phone adapters, aftermarket equipment (audio systems, security, remote start etc) and any devices wired into the OBD port. 3. DO NOT operate any vehicle feature that may

communicate on the data bus. This includes opening or closing of hood, doors, windows, as well as changing settings on radio, HVAC, connecting/removing charging devices etc. 4. Check Available Licenses. The first time

FlashScan/AutoCal flashes a controller, licensing requirements are validated and must be met to facilitate a successful flash. Refer to the License Status knowledgebase article for further information.

5. Check the EFILive Error Code list. The code

displayed on FlashScan/AutoCal and in the EFILive software is an important diagnostic tool. Look up the error code number and obtain a detailed description of the cause and suggested solutions to your issue.

If you still have problems flashing; 1. Isolate fuses. Common communication problems are reported with the ABS, BCM, Radio, Info and Lift Pump fuses. 2. If flashing in high speed; revert to low speed flashing. 3. Use pass-thru reading/flashing rather than standalone reading/flashing. 4. LB7 & LLY Controller Recovery 5. To attempt to recover a failed flash for LB7 or

LLY;

Full Flash DO NOT REMOVE POWER FROM THE CONTROLLER. As long as the controller remains powered up, EFiLive's proprietary boot loader running in the controller will continue to wait for a successful full flash procedure. Retry the full flash procedure until it is successful.

POWER REMOVED FROM CONTROLLER.

If power has been removed from the controller, it may only be recovered if the flash was at least 15%-20% complete and the communications codes were reprogrammed to allow the controller to continue to operate in dead poll mode. Retry the full flash procedure.

If flashing it fails with a "no communications" error then the controller has probably been rendered inoperable and unrecoverable. The only way to recover the controller is to disassemble it and physically remove, reprogram and replace the flash chip on the main circuit board.

Calibration Only Flash

A calibration-flash failure is not critical and will generally not result in an unrecoverable controller. To recover from a failed calibration only flash, turn the ignition off, wait 30 seconds, turn the ignition back on, wait a further 10 seconds, then retry the calibration only flash.

If the calibration only flash continues to fail: 1. Remove battery power from the controller, by either removing the controller's fuse or by disconnecting the battery from the vehicle. 2. Wait 30 seconds. 3. Reconnect power. 4. Retry the calibration only flash.