

2011-2016 FORD 6.7L OPEN AIR INTAKE

Installation Guide

Read the complete guide before beginning. Keep removed hardware organized, follow all safety precautions, and verify all connections before operating the vehicle.



Disclaimer

By installing this product onto your vehicle, you assume all risk and liability associated with its use. , LLC. is not responsible for misuse of its products. By installing this prod , LLC. of any and all liability associated with its use.

The purchaser and end user releases, indemnities, discharges and holds harmless , LLC. from any and all claims, damages, causes of action, injuries, or expenses resulting from or relating to the use or installation of this product that is in violation of the terms and conditions on this page, the product disclaimer, and/or the product installation instructions. , LLC. will not be liable for any direct, indi rect, consequential, exemplary, punitive, statutory, or incidental damages or fines caused by the use or installation of this product.

Caution

Never work on a hot vehicle. Serious injury in the form of burns can result if the vehicle has been in use. Allow vehicle to cool prior to installation. Always wear eye protection when working on or under any vehicle.

2011-2016 ford 6.7L powerstroke open air intake



Installation reference - page 3

E. A. D.

C.

B.

A. Intake Tube D. Filter Clamp B. Intake Stand E. S&B Filter C. MAF Sensor Port



Installation reference - page 4

STEP 1

Begin by removing the factory intake. Start by disconnecting the MAF sensor and Filter Minder sensor plugs from the intake tube. If yours does not have a filter minder, then no worries, since it is not being used with the new intake anyways.

STEP 2

Next, unclip the clips from the edges of the factory intake box (there is 1 on each side), and pull the top of the box off, revealing the filter.

STEP 3

Now loosen the intake tube clamp, using your 8mm socket. You should then be able to separate the intake tube from the filter housing. Once separated, grab the filter housing and tug upwards while wiggling side to side, and this should free the housing from the bracket holding it to the truck (make sure the single rubber grommet stayed in the mounting bracket and is not stuck to the bottom of the intake housing, because you will need it for the new intake stand).

STEP 4

After the intake housing is out of the way, you should be able to disconnect the rest of the intake tubing all the way to the turbo. There should only be 1 clamp holding the intake tube to the turbo.



Installation reference - page 5

STEP 5

Now that everything is removed, begin by placing the large end of the 4x5" boot and the 5" clamp over the inlet of the turbo housing and partially tighten the boot to the housing (leave loose enough to give you room to insert the intake tube after). You will notice that the housing is oval shape and the boot & clamp are round, but this is normal and is meant to work just fine.

STEP 6

Continue by placing the 4" clamp over the small end of the 4x5" boot and insert the cor- intake tube. Once your angles are set, tighten the 5" clamp until it forms around the oval turbo housing, then tighten the 4" clamp to the intake tube, and make sure you have a good even seal with the boot on both ends but leave just a hair loose for adjustments. Use your 11mm socket.



Installation reference - page 6

Signal = Blue connector, pin 69 Ground = Blue connector, pin 49

Signal = Purple Ground = Black

STEP 7

From here go ahead and install the intake stand. Force the bottom pointed end of the stand into the open hole w/rubber grommet on the base of the factory intake bracket, and then using the hardware kit provided, mount the other end of the stand to the obvious piece that has been welded to the bottom of the intake tube. Step 8

Now take the oversized intake filter and place it onto the end of the intake tube. Tighten the included clamp so that it isn't loose, using your 8mm socket again.

STEP 9

Final step, is to reinsert the MAF sensor into the new follow the direction of the arrow, as it was originally (in general the arrow will point away from the filter). Hardware is included for this, but you can re-use the factory screws if you choose. Make sure that you have your angles correct so that your hood can close without hitting the intake anywhere, before tightening all of the clamps fully.



Installation reference - page 7

Signal = Blue connector, pin 69 Ground = Blue connector, pin 49

Signal = Purple Ground = Black

