

2020-2025 FORD POWERSTROKE EZ LYNK SWITCH INSTRUCTIONS

Installation Guide

Read the complete guide before beginning. Keep removed hardware organized, follow all safety precautions, and verify all connections before operating the vehicle.





Installation reference - page 2

1. Start by popping the hood on your truck and unpacking your switch.



Installation reference - page 2

2. Find a spot inside the cab to mount your switch. (there are no good mounting holes so you can drill a small hole and mount the switch as seen in the picture below using the template)



Installation reference - page 3

3. Locate the hood release cable where it is fed through the firewall behind the brake pedal.
4. Using a razor cut a slit into the hood release grommet on the firewall inside of the cab.
5. Inside the cab, locate a coat hanger/wire to use for feeding the wires into the engine bay, tape the switch wire ends to the end of your hanger/wire.
6. Pull the hanger/wire into the engine bay through the slit you cut in the grommet with the switch wires connected
7. After the coat hanger and wires are fed into the engine bay, remove the tape of the switch wires from the hanger/wire
8. Place conduit supplied with the switch over the wires to protect them.
9. Using the supplied connector, pin switch wires into the connector. There are only 2 wires that need to be connected and they can go in either hole.



Installation reference - page 4

10. Once the switch has been pinned to the supplied connector, disconnect the factory harness from the charge air temp sensor.



Installation reference - page 4

11. Plug the new switch connector in the truck harness which is right in the center of the picture above. Tape off the factory sensor connector in the picture below to prevent corrosion.



Installation reference - page 5



Installation reference - page 5

12. Secure the conduit and switch wired under the hood using zip ties.